

HighPROTEC-2 | PROTECTION TECHNOLOGY MADE SIMPLE

MRMV4-2 | MOTOR PROTECTION DEVICE



MRMV4

HighPROTEC

• DNP 3.0

- Multiple Communication
- with one device
- ANSI Menu structure
- Page Editor
- New front plate with USB
- IEC61850 with LC interface

FUNCTIONS

The MRMV4 is a protection relay which uses the latest Dual-Core-Processor Technology to provide precise and reliable protective functions. Also it is very easy to operate.

The MRMV4 provides all necessary functions to protect low and medium voltage motors at all power levels. The protection functions are based on current and voltage measurement and supervise all thermal conditions, motor start sequence, stall and locked rotor, undercurrent and incomplete sequence. Overcurrent functions and earth fault functions are also available as power protection, frequency and voltage elements. The motor operation can be monitored by statistic and trend recorders.

APPLICABLE FOR:

→ Low and high voltage asynchronous motors. Protection based on current and voltage measurement.

MOTOR PROTECTION

- → Thermal overload protection 49M
- → Locked rotor Protection 51LRS
- → JAM or Stall protection 51LR
- → Underload protection 37
- → Motor start 48
- → Starts per Hour 66
- \rightarrow Negative phase sequence (current unbalance) 46
- → Overcurrent/short circuit prot. 50P/51P
- → Earth overcurrent- and short circuit protection 50N/51N
- Reclosing lockout 86 \rightarrow
- → RTD supervision via optional external temperature box (Type MRMV4-B)

ADDITIONAL PROTECTION

- → 6 Overcurrent elements (nondir)
- → 4 Earth Overcurrent elements (nondir)
- → 2 Elements Residual Voltage
- → 4 Over-/Undervoltage elements
- → 6 Frequency elements
- → 6 Power protection elements
- → 2 Power Factor elements
- → Demand Management
- → THD Protection

PC TOOLS

- Setting and analyzing software \rightarrow Smart view for free
- \rightarrow Including page editor to design own pages

SUPERVISION FUNCTIONS

- → Breaker Failure, Trip Circuit Superv.
- \rightarrow Loss of Potential, Switch onto Fault

MOTOR START RECORDER

- Max. RMS values of phase currents \rightarrow
- \rightarrow Negative phase sequence currents
- \rightarrow Start duration
- Used thermal capacity \rightarrow
- Successful starts \rightarrow
- \rightarrow Temperature profile (optional)

STATISTIC RECORDER

- → Number of successful starts
- Average I2T values \rightarrow
- Average max. start current \rightarrow

ADDITIONAL RECORDERS

- → Disturbance recorder: 120 s non volatile
- Fault recorder: 20 faults \rightarrow
- \rightarrow Event recorder: 300 events
- Trend recorder: 4000 non volatile entries \rightarrow

COUNTERS

- History (e.g. Motor starts values, \rightarrow Alarms, Trips...
- \rightarrow Total Counters (e.g. Run Time...)

COMMUNICATION OPTIONS

- → IEC61850
- \rightarrow Profibus DP
- Modbus RTU or Modbus TCP \rightarrow
- IEC60870-5-103 \rightarrow
- DNP 3.0 (RTU, TCP, UDP) \rightarrow

COMMISSIONING SUPPORT

- → USB connection
- → Customizable Display (Single-Line, ...)
- Customizable Inserts \rightarrow
- \rightarrow Copy and compare parameter sets
- → Configuration files are convertible
- → Forcing and disarming of output relays
- \rightarrow Fault simulator: current and voltage
- Graphical display of tripping characteristics \rightarrow
- 7 languages selectable within the relay \rightarrow

ADDITIONAL HIGHLIGHTS

- → 4 Analog Outputs (Type MRMV4-B)
- → Long starting time for reduced voltage starts
- Emergency Start \rightarrow
- \rightarrow Incomplete sequence
- \rightarrow Anti-backspin time delay
- Permitted number of cold starts \rightarrow
- \rightarrow Supervision of starts per hour
- \rightarrow Mechanical load shedding
- Zero speed indication via input \rightarrow
- \rightarrow Motor stop inputs
- External alarm and trip inputs \rightarrow
- \rightarrow 4 setting groups

CONTROL AND SUPERVISION

→ of one breaker

LOGIC

→ Up to 80 logic equations for protection, control and monitoring


TIME SYNCHRONISATION

→ SNTP or IRIG-BOOX

FUNCTIONAL OVERVIEW

	Elements	ANSI
Protective Functions		
3, thermal overload protection		49M
time overcurrent and short circuit protection (non direction) instantaneous, definite time, characteristicsaccording to IEC60255, ANSI		50P, 51P
/oltage controlled overcurrent protection by means of adaptive parameters. /oltage dependent overcurrent protection Negative phase sequence overcurrent protection	6	51C 51V 51Q
2, unbalanced load protection with evaluation of the negative phase sequence current	2	46
G, earth time overcurrent and short circuit protection (non direction) instantaneous, definite time, characteristics according to IEC60255, ANSI	4	50N, 51N
< underload protection	2	37
Reclosing lockout		49R
ncomplete sequence		
AM protection	2	51LR
ocked rotor Protection		51LRS
Notor start		48
Starts per Hour		66
Start control input		
Reversing mode		
mergency start		
<, V>, V(t)<, under- and overvoltage protection, time dependent undervoltage protection	6	27, 59
/oltage asymmetry supervision (V012) /1, under and overvoltage in positive phase sequence system /2, overvoltage in negative phase sequence system	6	47
ach of the six frequency protection elements can be used as:	6	
 f< or f> (over- or under frequency supervision) df/dt rate of change of frequency (ROCOF) (f< and df/dt) or (f> and df/dt) combination of over-, under- and ROCOF) (f< and DF/DT) or (f> and DF/DT) combination of over-, under- and increase of frequency Delta Phi (Vector surge) 		81U/O 81R 78
(X, residual voltage protection	2	59N
QS, Power protection	6	32, 37
F, Power factor	2	55
Control and Logic Control: Position indication, supervision time management and interlockings a breaker		
Logic: Up to 80 logic equations, with 4 inputs, selectable logical gates, timers and memory function		
Supervision Functions	1	EODE /CODE
BF, circuit breaker failure protection	1	50BF/62BF
CS, trip circuit supervision	1	74TC
OP, loss of potential	1	60FL
TS, current transformer supervision	1	60L
OTF, switch onto fault	1	
Demand management and peak value supervision (current and power)		
HD supervision		
reaker wear with programmable wear curves		
ecorders: Disturbance, fault, event, trend, start and statistic recorders		

FUNCTIONAL OVERVIEW IN ANSI FORM



APPROVALS

CE



certified regarding UL508 (Industrial Controls)



certified regarding CSA-C22.2 No. 14 (Industrial Controls)

Type tested according to IEC60255-1




certified by EAC (Eurasian Conformity)

complies with IEEE 1547-2003 amended by IEEE 1547a-2014

complies with ANSI C37.90-2005

CONNECTIONS (EXAMPLE)



ORDER FORM MRMV4-2

Motor Pro	otection				MRMV4	-2				
Version 2 with USB, enhanced communication and user options										
Digital Inputs	Binary output relays	Analog Inputs/ Outputs	Housing	Large display			L			
8	7	0/4	B2	-			Α			
8	13	0/4	B2	-			С			
Hardware	variant 2									
Phase Current 5 A/1 A, Ground Current 5 A/1 A								0		
Phase Current 5 A/1 A, Sensitive Ground Current 5 A/1 A								1		
Housing a	and mounting									
Door mounting								Α		
Door mou	nting 19" (flush m	ounting)							В	
	ication protocol									
Without pr	rotocol									А
Modbus RTU, IEC60870-5-103, DNP3.0 RTU <i>RS485/terminals</i>										B *
Modbus TCP, DNP3.0 TCP/UDP Ethernet 100 MB/RJ45									C*	
	P optic fiber/ST-c	onnector								D*
Profibus-DP <i>RS485/D-SUB</i>									E*	
Modbus RTU, IEC60870-5-103, DNP3.0 RTU <i>optic fiber/ST-connector</i>									F*	
Modbus RTU, IEC60870-5-103, DNP3.0 RTU <i>RS485/D-SUB</i>									G*	
		3.0 TCP/UDP Ether								H*
		"U, DNP3.0 RTU RS DP Ethernet 100 M		5						*
IEC61850, Modbus TCP, DNP3.0 TCP/UDP Optical Ethernet 100MB/LC duplex connector									K*	
Modbus TCP, DNP3.0 TCP/UDP Optical Ethernet 100MB/LC duplex connector									L*	
Harsh Env	vironment Optio	on								
None										
Conformal	Coating									

Available menu languages (in every device)

Standard English/German/Spanish/Russian/Polish/Portuguese/French

* Within every communication option only one communication protocol is usable. Smart view can be used in parallel via the Ethernet interface (RJ45).

The parameterizing- and disturbance analyzing software Smart view is included in the delivery of HighPROTEC devices.

Current inputs Voltage inputs Digital Inputs Power supply

Terminals Type of enclosure Dimensions of housing (W x H x D)

Weight (max. components)

4 (1 A and 5 A) with automatic CT Disconnect 4 (0–800 V) Switching thresholds adjustable via software Wide range power supply 24 V_{DC} - 270 V_{DC} / 48 V_{AC} - 230 V_{AC} (-20/+10%) All terminals plug type IP54 19" flush mounting: 212.7 mm x 173 mm x 208 mm 8.374 in. x 6.811 in. x 8.189 in. Door mounting: 212.7 mm x 183 mm x 208 mm 8.374 in. x 7.205 in. x 8.189 in. approx. 4.2 kg / 9.259 lb

CONTACT:

North & Central America

Phone: +1 970 962 7331 E-mail: SalesPGD_NAandCA@woodward.com

South America

Phone: +55 193708 4800 E-mail: SalesPGD_SA@woodward.com

Europe

Phone: +49 2152 145 331 E-mail: SalesPGD_EUROPE@woodward.com

Middle East & Africa

Phone: +971 2 6275185 E-mail: SalesPGD_MEA@woodward.com

Russia

Phone: +7 812 319 3007 E-mail: SalesPGD_RUSSIA@woodward.com

China

Phone: +86 512 8818 5515 E-mail: SalesPGD_CHINA@woodward.com

India

А

В

Phone: +91 124 4399 500 E-mail: SalesPGD_INDIA@woodward.com

ASEAN & Oceania

Phone: +49 711 78954 510 E-mail: SalesPGD_ASEAN@woodward.com



© Woodward All Rights Reserved | 09/2015